



INSTRUCTION NO. 5

REPLACEMENT WINDOWS

Replacement windows for Item Nos. 1023, 1031, 1036, 1040, 1042, 1044, and 1045, are furnished untrimmed. When installing these windows, place them against their respective metal window frames (no rubber molding in place) and scribe the outline of the frame opening on the plexiglass. Then, using a set of dividers, scribe another line one quarter of an inch inside the first line. Trim window to this line using a saw, and grind or file to size. Be sure not to heat plexiglass too much with grinder.

RC-3-5
2/3/47