

**SEABEE SPARE PARTS
PRICE LIST FOR CATALOG
NO. 1000**

MARCH 1, 1947

NOTE:

Prices in this list refer to items appearing in Seabee Parts Catalog #1000. Numerous changes have been made since this catalog was printed; therefore, this price list includes cancellations and additions not appearing in the catalog. When ordering, list parts required by item number and nomenclature and, if possible, Seabee serial number. Prices quoted are F.O.B. Farmingdale, New York, include the cost of crating or packaging and are subject to change without notice, in accordance with the terms and conditions of the Republic Distributor Agreement.

**REPUBLIC AVIATION CORPORATION
FARMINGDALE LONG ISLAND NEW YORK**

Item No.	Nomenclature	Code	List Price
1081	Trim Tab - Left Hand Elevator.....	A	3.93
1082	Elevator - Right Hand Including Trim Tab.....	A	104.15
1083	Trim Tab - Right Hand Elevator.....	A	3.93
1084	Cancelled.....		
1085	Quadrant Assembly - Rudder.....	A	2.15
1086	Cancelled.....		
1087	Rudder - Water.....	A	5.27
1088	Post - Water Rudder.....	A	3.94
1089	Cancelled.....		
1090	Strut Assembly - Left Hand Landing Gear.....	C	94.69
1091	Flange - Landing Gear Brake.....	C	3.08
1092	Axle - Landing Gear Strut.....	C	5.08
1093	Scissors - L.G. Strut (1-500) (See 1491).....	C	7.45
1094	Gasket Kit - Landing Gear Strut.....	A	1.99
1095	Valve - Landing Gear Strut Hi-Pressure Air.....	A	1.22
1096	Wheel & Brake Assembly - Landing Gear.....	C	54.97
1097	Brake Assembly - Landing Gear.....	C	23.33
1098	Wheel - Landing Gear.....	C	31.90
1099	Bearing Set - Landing Gear Wheel.....	A	2.35
1100	Tire - Landing Gear Aircraft.....	C	22.55
1101	Tube - Landing Gear Aircraft - Inner.....	C	6.60
1102	Tube - Landing Gear Cross.....	C	14.71
1103	Nut - Landing Gear Axle.....	A	1.47
1104	Collar - Landing Gear Wheel.....	A	.55
1105	Cancelled.....		
1106	Strut Assembly - Right Hand Landing Gear.....	C	94.69
1107	Cancelled.....		
1108	Bearing - L.G. Cross Tube Outboard.....	A	4.44
1109	Bearing - Landing Gear Cross Tube Inboard.....	A	3.34
1110	Tube Assembly - Landing Gear Actuator Torque.....	C	14.54
1111	Link - Landing Gear Actuator Upper Lock.....	C	2.88
1112	Link - Landing Gear Actuator Lower Lock.....	C	13.44
1113	Spring - Landing Gear Actuator Down Lock.....	A	1.22
1114	Kit - Packing - Fuel Shut Off Valve.....	A	.55
1115	Kit - Packing - Landing Gear Retracting Cylinder..	A	1.62
1116	Cancelled.....		
1117	Spacer - Tail Wheel.....	A	.10
1118	Tire - Tail Wheel Aircraft.....	C	15.35
1119	Tube - Tail Wheel Aircraft - Inner.....	C	3.70
1120	Axle - Tail Wheel.....	A	1.07
1121	Shim - Tail Wheel Shaft.....	A	.22
1122	Yoke Assembly - Tail Wheel.....	A	56.95
1123	Fork Assembly - Tail Wheel.....	A	39.87
1124	Spacer - Tail Wheel Shock Absorber.....	A	.10
1125	Shaft - T.W. Shock Absorber (1-125) (See 1452)....		No Price
1126	Collar - T.W. Shock Absorber Tube (1-125).....		
	(See 1453).....	A	37.15
1127	Tube - Tail Wheel Shock Absorber.....	A	3.77
1128	Piston - T.W. Shock Absorber (1-125) (See 1487)...	A	3.54
1129	Disc & Plate Set-T.W. Shock Absorber (1-125).....		
	(See 1486).....	A	11.95
1130	Bearing Assembly - Tail Wheel Down Lock.....	A	6.97
1131	Cancelled.....		
1132	Spring - Tail Wheel Lock.....	A	.55
1133	Bracket Assembly - Tail Wheel Pulley.....	A	4.04
1134	Sleeve - T.W. Shock Absorber (1-125) (See 1454)....	A	2.74
1135	Plate Assembly - Tail Wheel Yoke Friction.....	A	2.25
1136	Tube Assembly - Tail Wheel Actuating Torque.....	A	6.50
1137	Link Assembly - Tail Wheel Actuating - Lower.....	A	2.34
1138	Tube Assembly - Tail Wheel Actuating.....	A	6.35
1139	Support - Tail Wheel Actuating Tube.....	A	.92
1140	Shim - Tail Wheel Actuating Support.....	A	.22
1141	Fork - Tail Wheel.....	A	17.24
1142	Spindle - Tail Wheel.....	A	32.27
1143	Filler - Tail Wheel Fork Assembly.....	A	.42
1144	Cylinder - Tail Wheel Hydraulic Actuating.....	C	13.04
1145	Collar - Tail Wheel Actuating Forward.....	A	1.82
1146	Control - Parking Brake - Push Pull (125 & Up).....		
	(See 1153).....	B	.95
1147	Kit - Packing - Fuel Check Valve.....	A	.50
1148	Power Pak - Hydraulic System.....	C	54.38
1149	Cylinder - Landing Gear Retracting Hydraulic.....	C	18.61
1150	Cylinder - Wing Flap Hydraulic.....	C	11.91
1151	Kit Packing - Brake Cylinder.....	A	.52
1152	Valve Assembly - Parking Brake (1-125) (See 1429)...	C	6.84
1153	Control - Parking Brake Push-Pull(1-125)(See 1146)	B	.93
1154	Connector - Brake Hydraulic Bleeder.....	A	5.37
1155	Cancelled.....		
1156	Nut - Brake Hydraulic Bleeder Connector.....	C	.10
1157	Cylinder - Master Brake.....	C	8.20
1158	Bellcrank - Right Hand Aileron Control.....	A	3.40

Item No.	Nomenclature	Code	List Price
1001	Cancelled.....	A	1,234.82
1002	Hull Ass'y. - Fwd. (From Nose to Step).....	A	42.43
1003	Skin - Right Hand Bottom Bow.....	A	42.43
1004	Skin - Left Hand Bottom Bow.....	A	28.25
1005	Keel - Forward Section.....	A	178.47
1006	Keel and Bottom Bow Skins Ass'y.....	A	179.45
1007	Bottom Ass'y. - Intermediate Hull.....	A	36.38
1008	Skin - Left Hand Hull Bow.....	A	36.38
1009	Skin - Right Hand Hull Bow.....	A	87.90
1010	Floor Ass'y. - Forward Cabin.....	A	.69
1011	Door - Landing Gear Access.....	A	.55
1012	Door - Deck Access.....	C	.11
1013	Button - Forward Cabin Floor Plug.....	A	1.75
1014	Cover - Battery Box.....	A	5.10
1015	Step - Left Hand Passenger.....	A	5.10
1016	Step - Right Hand Passenger.....	A	723.08
1017	Hull Ass'y. - Aft. (From Step to Tail).....	A	1.24
1018	Cover - Hull Handhole.....	A	21.90
1019	Keel - Aft. Section.....	A	288.97
1020	Hull Boom - (From T.W. Splice to Tail).....	A	11.64
1021	Kit - Handhole Covers & Access Doors.....	A	168.07
1022	Door - Left Hand Cabin Complete.....	A	25.04
1023	Window - L.H. Cabin Door With Clearview Panel and Molding.....	A	1.85
1024	Ventilator - Cabin Windows.....	A	1.27
1025	Seal - L.G. Cross Tube Outboard Bearing.....	C	2.75
1026	Molding - Cabin Door Window.....	A	4.62
1027	Lock - L.H. Cabin Door Complete With Key.....	A	2.14
1028	Cancelled.....	A	160.55
1029	Stop - Left Hand Cabin Door Sliding.....	A	19.49
1030	Door - Right Hand Cabin Complete.....	A	3.50
1031	Window - Right Hand Cabin Door With Molding.....	A	42.97
1032	Lock - Right Hand Cabin Door Complete.....	A	2.14
1033	Mount Installation - Engine.....	A	125.48
1034	Stop - Right Hand Cabin Door Sliding.....	A	23.99
1035	Door - Cabin Bow Complete.....	A	2.75
1036	Windshield - Cabin Bow Door With Molding.....	A	4.94
1037	Molding - Cabin Bow Door Windshield.....	A	26.77
1038	Lock - Cabin Bow Door Complete With Key.....	A	2.75
1039	Cancelled.....	A	25.77
1040	Windshield - L.H. Cabin Bow With Molding.....	A	1.87
1041	Molding - L.H. Cabin Bow Windshield.....	A	12.45
1042	Window - Cabin Crown With Vents & Molding.....	A	12.45
1043	Molding - Cabin Crown Window.....	A	1.87
1044	Window - L.H. Cabin Rear, With Molding.....	A	34.14
1045	Window - R.H. Cabin Rear, With Molding.....	A	24.77
1046	Molding - Cabin Rear Window.....	A	3.22
1047	Skin - Left Hand Cabin Bow.....	A	577.10
1048	Skin - Right Hand Cabin Bow.....	A	87.38
1049	Skin - Center Cabin Bow.....	A	17.70
1050	Wing Ass'y. - Left Hand Less Flap & Aileron....	A	72.75
1051	Cancelled.....	A	3.05
1052	Float - Wing.....	A	54.08
1053	Strut - Wing Float.....	A	4.27
1054	Strut - Wing Lift With Fairing Left Hand.....	A	76.25
1055	Fairing - Wing Lift Strut Upper Right Hand.....	A	3.75
1056	Tip - Left Hand With Navigation Light.....	A	3.94
1057	Light - Wing Tip Navigation - Red.....	A	3.40
1058	Aileron - Left Hand.....	A	3.45
1059	Cable Ass'y. - Left Hand Aileron Balance.....	A	4.05
1060	Cable Ass'y. - Aileron Control - Wing L.H.....	A	88.82
1061	Bellcrank - Left Hand Aileron Control.....	A	2.02
1062	Bracket Assembly - Aileron Support.....	A	5.28
1063	Rod Ass'y. - Aileron Bellcrank Control.....	A	577.10
1064	Flap - Wing.....	A	7.45
1065	Bracket - Flap Support.....	A	54.08
1066	Tube - L.H. Wing Pitot (1-169) (See 1474).....	A	4.25
1067	Wing Ass'y. - R.H. - Less Flap & Aileron.....	A	142.47
1068	Fairing - Wing Lift Strut Lower - Left Hand.....	A	2.04
1069	Tip - R.H. Wing With Navigation Light.....	A	111.05
1070	Kit - Packing - Brake Adjuster.....	A	123.73
1071	Fin Complete.....	A	1.35
1072	Light - Fin Anchor.....	A	1.49
1073	Rudder - Air Complete.....	A	123.73
1074	Stabilizer - Left Hand - With Tab Controls.....	A	104.15
1075	Hinge - Stabilizer Outboard.....	A	.90
1076	Hinge - Stabilizer Inboard.....	A	.82
1077	Stabilizer - Right Hand With Tab Controls.....	A	
1078	Elevator - Left Hand Including Trim Tab.....	A	
1079	Hinge - Elevator Inboard.....	A	
1080	Hinge - Elevator Outboard.....	A	

Item No.	Nomenclature	Code	List Price
1159	Gage - Oil Temperature (1-425) (See 1517).....	B	5.50
1160	Tachometer - Engine (1-425) (See 1516).....	B	19.00
1161	Shaft - Engine Tachometer (1-425) (See 1513).....	B	11.25
1162	Panel Ass'y. Inst. - Bare (1-425) (See 1422).....	A	12.38
1163	Bearing Ass'y. - Instrument Panel Control Column...	A	2.00
1164	Cancelled.....		No Price
1165	Panel Assembly - Cross Country Instrument.....	A	70.00
1166	Compass.....	B	55.00
1167	Panel Ass'y.-Engine Instrument(1-425) (See 1421)...		
1168	Cancelled.....		
1169	Cancelled.....		
1170	Cancelled.....		
1171	Cancelled.....		
1172	Cancelled.....		
1173	Altimeter - Sensitive.....	A	70.50
1174	Indicator - Airspeed.....	C	25.50
1175	Indicator - Bank and Turn.....	A	85.50
1176	Glock - Right Day.....	A	38.18
1177	Drive - Engine Tachometer Rt.Angle (1-425) Only.....	B	6.50
1178	Gage - Fuel Quantity Indicating(1-425) (See 1518)...	B	5.50
1179	Gage - Manifold Pressure.....	C	34.50
1180	Radio Set.....	B	110.00
1181	Pipe Assembly - Fuel Filler Neck With Cap.....	A	4.45
1182	Valve - Brake Adjuster.....	A	9.25
1183	Ammeter (1-425) (See 1521).....	B	5.50
1184	Battery - Electric Storage.....	A	35.00
1185	Antenna Assembly - Radio.....	A	6.87
1186	Anchor Assembly - Wing Antenna - L.H.....	A	1.94
1187	Anchor Assembly - Fin Antenna (1-500) (See 1494)...	A	2.22
1188	Fairing Set - Left Hand Wing to Cabin.....	A	28.00
1189	Fairing Set - Right Hand Wing to Cabin.....	A	28.00
1190	Panel - Left Hand Cabin Door Clearview.....	A	7.22
1191	Cable Assembly - Right Hand Aileron Balance.....	A	3.75
1192	Pedal Assembly - Pilots Brake (1-125) (See 1432)...	B	15.00
1193	Arm - Pilot Brake Pedal (1-125) (See 1434).....	A	10.00
1194	Pedal - Pilot Brake (1-125) (See 1436).....	C	5.00
1195	Pedal Ass'y. - Co-Pilot Rudder (1-125) (See 1437)...	A	5.47
1196	Arm - Co-Pilot Rudder Pedal (1-125) Only.....	A	5.47
1197	Pedal - Co-Pilot Rudder (1-125) Only.....	C	1.50
1198	Angle - Pilots Brake Pedal Support - L.H. (1-125) (See 1438).....	A	2.95
1199	Angle - Pilots Brake Pedal Support - R.H. (1-125) (See 1439).....	A	3.02
1200	Tube Assembly - Rudder and Brake Pedal Torque.....	A	5.62
1201	Gear - Rudder & Brake Pedal Torque Tube.....	A	.95
1202	Stop - Bow Door.....	A	1.47
1203	Cancelled.....		
1204	Arm Assembly - Co-Pilot Control Wheel.....	A	28.05
1205	Arm - Pilot Control Wheel.....	A	5.30
1206	Arm - Co-Pilot Control Wheel.....	A	6.79
1207	Sprocket - Control Wheel Horizontal Inner Tube.....	A	1.65
1208	Chain - Control Arm.....	A	1.75
1209	Sprocket - Control Wheel Arm Upper.....	A	1.40
1210	Sprocket - Co-Pilot Control Wheel Arm Lower.....	A	1.57
1211	Housing - Pilot Control Wheel Arm.....	A	6.95
1212	Cover - Control Wheel Arm.....	A	1.02
1213	Chain - Elevator Trim Tab Control (Forward).....	A	4.39
1214	Wheel Assembly - Control.....	A	11.27
1215	Button - Control Wheel Arm Housing Plug.....	C	.08
1216	Ring - Co-Pilot Control Wheel Arm Retaining.....	C	.10
1217	Tube Ass'y. - Control Wheel Column (1-300) (See 1490).....	A	16.45
1218	Tube Ass'y. - Control Wheel Horizontal (1-300) (See 1441).....	A	20.25
1219	Push Rod - Control Wheel Column Lower Quadrant.....	A	4.83
1220	Side Brace - Control Wheel Column.....	A	1.39
1221	Support - Control Wheel Column Lower.....	A	1.87
1222	Support - Control Wheel Column Side Brace Lower....	A	1.87
1223	Quadrant - Control Wheel Column Lower.....	A	3.95
1224	Support - Control Wheel Column Lower Quadrant.....	A	2.16
1225	Pin - Co-Pilot Control Arm Release.....	A	.32
1226	Cancelled.....		
1227	Angle - Co-Pilot Rudder Pedal Support (1-125) (See 1440).....	A	2.33
1228	Spring - Water Rudder Cable.....	A	.35
1229	Kit - Packing - Wing Flap Cylinder.....	A	1.22
1230	Plate Assembly - Tail Wheel Fork Retaining.....	A	2.57
1231	Washer - Tail Wheel Fork Retaining Spring.....	A	.82
1232	Angle-Rudder Pedal Torque Tube Supp.(1-125) (See (1442).....	A	1.95
1233	Valve - Suction Throttling.....	C	5.50

Item No.	Nomenclature	Code	List Price
1234	Cancelled.....		
1235	Control Assembly - Trim Tab.....	A	10.92
1236	Crank Assembly - Trim Tab Control.....	A	.57
1237	Tube - Trim Tab Control Chain.....	A	1.65
1238	Cover - Rudder Cable Cabin (1-125) (See 1443)...	A	2.55
1239	Cover - Fwd. Cabin Control Cables (1-300) (See 1444).....	A	3.77
1240	Cover - Intermediate Cabin Control Cables.....	A	3.12
1241	Cover - Aft. Cabin Control Cables.....	A	2.82
1242	Cable Assembly - Aileron Hull.....	A	7.02
1243	Cable Assembly - Left Hand Hull Rudder.....	A	3.64
1244	Cable Assembly - Right Hand Hull Rudder.....	A	3.65
1245	Cable Assembly - Aft. Hull Rudder.....	A	11.22
1246	Cable Assembly - Elevator Hull.....	A	8.54
1247	Clip - Trim Tab Control Chain Spring.....	B	.10
1248	Casing Ass'y. - Elevator Trim Tab Control Lower.....	A	3.93
1249	Valve - Fuel Check (Ships 1-125) (See 1445).....	B	6.00
1250	Cancelled.....		
1251	Fuel Cell.....	A	68.85
1252	Cover Assembly - Fuel Cell.....	A	8.97
1253	Screen Assembly - Fuel Cell.....	A	2.05
1254	Drain Assembly - Fuel Cell.....	A	3.09
1255	Cancelled.....		
1256	Washer - Fuel Drain.....	A	.10
1257	Gasket - Fuel Drain Lower.....	A	.10
1258	Gasket - Fuel Cell.....	A	.57
1259	Cock - Fuel Drain.....	B	.50
1260	Bracket - Fuel Cell Hose.....	A	.50
1261	Gasket - Fuel Drain Upper.....	A	.20
1262	Ring - Fuel Cell.....	A	5.97
1263	Hose - Fuel Cell Outlet.....	A	4.30
1264	Gasket - Fuel Measuring Unit.....	A	.20
1265A	Kit - Fire Extinguisher Installation.....	A	15.00
1266B	Kit - Anchor Installation.....	A	28.45
1267	Tank Unit - Fuel Measuring (1-425) (See 1524)...	A	4.40
1268	Grommet - Filler Neck.....	A	.12
1269	Cap Assembly - Filler Neck.....	A	.55
1270	Hose - Filler Neck.....	A	.74
1271	Strainer - Fuel (1-300) (See 1458).....	B	6.36
1272	Casing Assembly - Trim Tab Control Upper.....	A	3.62
1273	Cancelled.....		
1274	Propeller - Hartzell Mod. HC 12X20-2.....	C	395.00
1275	Engine - Franklin Model 6A1500.....	D	1,695.00
1276	Gage - Fuel Pressure (1-425) (See 1520).....	B	5.50
1277	Gage - Oil Pressure (1-425) (See 1519).....	B	5.50
1278	Circuit Breaker - 10 Ampere.....	A	.66
1279	Circuit Breaker - 40 Ampere.....	A	.66
1280	Bulb - Instrument Panel or L.G. Position Ind.....	A	.15
1281	Transmitter - Oil Pressure (1-425) Only.....	B	6.55
1282	Transmitter - Fuel Pressure (1-425) Only.....	B	6.55
1283	Cancelled.....		
1284	Transmitter - Oil Temperature (1-425) Only.....	B	6.55
1285	Control - Battery Switch Push-Pull.....	B	.94
1286	Switch Assembly - Battery.....	A	3.44
1287	Switch - Master.....	B	1.56
1288	Switch - Ignition & Starter Battery Magneto (501 & Up) (See 1289).....	A	7.10
1289	Switch - Ignition & Starter Dual Magneto (1-500) (See 1288).....	A	6.10
1290	Switch Assembly - Instrument Light.....	A	1.40
1291	Switch - Fuel Pressure Selector (1-425) Only....	B	.82
1292	Switch-Cabin Dome Light; Navigation Light Anchor Light.....	B	.60
1293	Switch - Landing Gear Position Indicating Light	A	2.62
1294	Jewel - L.G. Position Indicator Light - Red.....	A	.11
1295	Disconnect - Electrical System Quick.....	A	.10
1296	Light - Cabin Dome.....	A	1.50
1297	Cancelled.....		
1298	Hold-Down - Battery.....	A	.10
1299	Bolt - Battery Hold-Down.....	A	.17
1300	Cable - Battery Ground Electric.....	A	1.02
1301	Jewel - L.G. Position Indicator Light - Green....	A	.11
1302	Light - R.H. Wing Tip Navigation - Green.....	A	4.27
1303	Tube Assembly - Left Hand Engine Mount.....	A	7.57
1304	Tube Assembly - Right Hand Engine Mount.....	A	7.57
1305	Channel Assembly - Engine Mount Forward.....	A	5.52
1306	Channel Assembly - Engine Mount Rear.....	A	5.77
1307	Mount Assembly - Rear Engine Shock.....	A	4.18
1308	Mount Assembly - Front Engine Shock.....	A	4.35
1309	Cowl Assembly - Right Hand Lower Engine.....	A	64.13
1310	Cowl Assembly - Left Hand Lower Engine.....	A	60.90

<u>Item No.</u>	<u>Nomenclature</u>	<u>Code</u>	<u>List Price</u>
1311	Cowl Assembly - Top Engine.....	A	120.87
1312	Cowl Assembly - Front Engine.....	A	120.62
1313	Link - Front Engine Cowl - Forward.....	A	.82
1314	Link - Front Engine Cowl - Rear.....	A	.87
1315	Bracket Assembly - Front Engine Cowl Left Hand.....	A	1.59
1316	Bracket Assembly - Front Engine Cowl Right Hand.....	A	1.59
1317	Grille Assembly - Front Engine Cowl.....	A	11.12
1318	Latch Assembly - Engine Cowl.....	A	1.30
1319	Bracket Ass'y. - Forward Cowl Support Left Hand.....	A	2.97
1320	Bracket Ass'y. - Forward Cowl Support Right Hand.....	A	3.42
1321	Bracket Assembly - Rear Cowl Support Left Hand.....	A	3.85
1322	Bracket Assembly - Rear Cowl Support Right Hand.....	A	3.85
1323	Aileron - R.H. With Ground Adjustable Tab.....	A	76.90
1324	Sprocket Assembly - Elevator Trim Tab.....	A	1.32
1325	Gear Assembly - Elevator Trim Tab Left Hand.....	A	20.25
1326	Gear Assembly - Elevator Trim Tab Right Hand.....	A	20.25
1327	Rod Ass'y. - Elev. Trim Tab (1-307)(See 1502,150, and 1504).....	A	1.90
1328	Fork - Elevator Trim Tab (1-307) Only.....	A	.60
1329	Shaft Assembly - Elevator Trim Tab Flexible.....	A	1.75
1330	Cable - Battery to Battery Switch Electric.....	A	.85
1331	Cable - Engine Ground Electric.....	A	1.04
1332	Harness - Cabin Elec.Wiring (1-425) (See 1514).....	A	41.61
1333	Harness - Engine Elec.Wiring (1-425) (See 1515).....	A	11.87
1334	Upholstery - Left Hand Side Panel.....	A	10.79
1335	Upholstery - Right Hand Side Panel.....	A	10.79
1336	Mat - Cabin Floor Rear (151 & Up).....	A	2.12
1337	Upholstery - Bow Panel.....	A	3.59
1338	Upholstery - Head Liner.....	A	13.32
1339	Upholstery - Bulkhead - Baggage Compartment.....	A	12.69
1340	Upholstery - Firewall.....	A	2.64
1341	Upholstery - Door Post R.H.....	A	12.54
1342	Upholstery - Baggage Compartment Door.....	A	2.80
1343	Cancelled.....		
1344	Pin - Bow Door Hinge.....	A	.10
1345	Pin - Side Door Hinge.....	A	.10
1346	Door Assembly - Baggage Compartment.....	A	8.27
1347	Strap - Front Assist.....	A	1.30
1348	Strap - Rear Assist.....	A	1.30
1349	Track - Left Hand Front Seat.....	A	2.95
1350	Track - Right Hand Front Seat.....	A	2.95
1351	Cancelled.....		
1352	Frame Assembly - Front Seat.....	A	47.02
1353	Frame Assembly - Rear Seat.....	A	16.82
1354	Seat Back - Front.....	A	6.84
1355	Seat Back - Rear.....	A	9.92
1356	Cushion - Seat.....	A	14.79
1357	Box Assembly - Battery.....	A	21.99
1358	Upholstery - Left Hand Side Door.....	A	12.69
1359	Upholstery - Right Hand Side Door.....	A	12.69
1360	Upholstery - Bow Door.....	A	6.02
1361	Plug - Keel Wing Float Drain (Set of 7).....	A	2.25
1362	Cancelled.....		
1363	Fan Housing - Engine With Forward Baffle.....	A	32.40
1364	Baffle Assembly - Right Hand Engine Cylinder.....	A	3.00
1365	Baffle Assembly - Left Hand Engine Cylinder.....	A	3.36
1366	Baffle - Left Hand Rocker Box.....	A	4.72
1367	Baffle - Right Hand Rocker Box.....	A	4.10
1368	Baffle - Left Hand Rear Engine.....	A	6.68
1369	Baffle - Right Hand Rear Engine.....	A	6.70
1370	Apron Assembly - Front Cowl.....	A	16.12
1371	Clamp - Engine Exhaust Tail Pipe.....	A	1.75
1372	Bearing Set - Tail Wheel.....	A	1.77
1373	Locking Handle - L.H. Cabin Door.....	A	2.54
1374	Locking Handle - Cabin Bow Door.....	A	2.54
1375	Ash Tray - Cabin.....	B	.58
1376	Mat - Cabin Floor L.H. Fwd. (1-425) (See 1459).....	A	3.73
1377	Tube Assembly - Left Hand Engine Blast.....	A	26.04
1378	Tube Assembly - Right Hand Engine Blast.....	A	26.04
1379	Button - Elevator, Rudder, or Stabilizer Plug.....	C	.03
1380	Control Unit - Reversible Pitch Propeller.....	A	5.23
1381	Lever - Propeller Reverse Control.....	A	.69
1382	Spring - Propeller Reverse Control.....	A	.19
1383	Knob - Propeller Reverse Control.....	B	.37
1384	Plate - Propeller Reverse Control Instruction.....	A	.50
1385	Bracket - Reversible Propeller Control.....	A	.92
1386	Bolt - Mixture Control Attachment.....	B	.22
1387	Throttle Control - Push Pull.....	B	9.90
1388	Pitch Control - Propeller.....	B	8.14
1389	Mixture Control.....	B	2.01
1390	Heat Control - Carburetor.....	B	1.98
1391	Cancelled.....		

Item No.	Nomenclature	Code	List Price
1392	Molding - Engine Cowl Rubber.....	A	1.00
1393	Control - Propeller Reverse Cable.....	B	1.23
1394	Lock Ass'y. - Propeller Reverse Control.....	A	1.06
1395	Hose Ass'y. - Prop. Pitch Change Hydraulic Pressure (1-125) (See 1493).....	A	3.20
1396	Hose Ass'y. - Prop. Pitch Change Hydraulic Return (1-125) (See 1493).....	A	3.50
1397	Valve - Propeller Pitch Check.....	B	4.80
1398	Gasket - Propeller Cylinder.....	A	.14
1399	Kit - Packing - Power Pak.....	A	5.80
1400	Kit - Packing - Tail Wheel Cylinder.....	A	1.75
1401	Cancelled.....		
1402	Clip - Landing Gear Lock Spring.....	A	.25
1403	Fairing - Wing Lift Strut Lower Right Hand.....	A	7.70
1404	Clamp Assembly - Exhaust Shroud Forward.....	A	.67
1405	Clamp Assembly - Exhaust Shroud Aft.....	A	.67
1406	Shroud Assembly - Exhaust.....	A	5.52
1407	Duct Assembly - Induction System.....	A	6.25
1408	Intake - Carburetor Air.....	A	11.20
1409	Housing - Carburetor Air Filter.....	A	38.25
1410	Gasket - Carburetor Air Intake.....	A	.10
1411	Tube Assembly - Hot Air Induction System.....	A	3.84
1412	Filter - Air.....	B	7.25
1413	Bladder - Seat Back.....	A	4.02
1414	Seal - Tail Wheel Downlock Bearing Oil.....	C	2.08
1415	Fairing - Wing Lift Strut Upper - Left Hand.....	A	1.78
1416	Gasket - Cabin Window Ventilators.....	A	.40
1417	Cover - Anchor Stowage Hatch (151 & Up).....	A	3.74
1418	Strut - Wing Lift With Fairings - Right Hand.....	A	72.75
1419	Cable Assembly - Aileron Control - Wing R.H.....	A	3.87
1420	Light - Rudder Navigation.....	A	2.04
1421	Panel Ass'y. - Engine Inst. (426 & Up) (See 1167).....	C	35.00
1422	Panel-Instrument Mount (426 & Up) (See 1162).....	A	12.38
1423	Decorative Panel - Cross Country Instruments.....	A	10.25
1424	Upholstery - Door Post - Left Hand.....	A	4.17
1425	Cancelled.....		
1426	Wheel Assembly - Tail.....	C	19.00
1427	Kit - Packings - Complete Hydraulic System.....	A	13.57
1428	Valve - Fuel Shut-Off - Plug (1-125) (See 1481).....	B	9.00
1429	Valve Ass'y. - Parking Brake (126 & Up) (See 1152).....	C	5.08
1430	Cancelled.....		
1431	Anchor Ass'y. - Wing Antenna Right Hand.....	A	1.90
1432	Pedal Ass'y. - Pilot's Brake L.H. (126 & Up) (See 1192).....	A	7.90
1433	Pedal Ass'y. - Pilot's Brake R.H. (126 & Up) (See 1192).....	A	7.90
1434	Arm - Pilot's Brake Pedal L.H. (126 & Up) (See 1193).....	A	3.82
1435	Arm - Pilot's Brake Pedal R.H. (126 & Up) (See 1193).....	A	4.90
1436	Pedal - Pilot Brake (126 & Up) (See 1194).....	A	3.89
1437	Pedal Ass'y. - Co-Pilot Rudder (126 & Up) (See 1195).....	A	3.49
1438	Angle - Pilot Brake Pedal Support Left Hand (126 & Up) (See 1198).....	A	.85
1439	Angle - Pilot Brake Pedal Support Right Hand (126 & Up) (See 1199).....	A	1.37
1440	Angle - Co-Pilot Rudder Pedal Support (126 & Up) (See 1227).....	A	.97
1441	Tube Ass'y. - Control Wheel Horizontal (301 & Up) (See 1218).....	A	22.17
1442	Angle Rudder Pedal Torque Tube Support (126 & Up) (See 1232).....	A	.47
1443	Cover-Rudder Cable Chain (126 & Up) (See 1238).....	A	2.52
1444	Cover - Fwd. Cabin Control Cables (301 & Up) (See 1239).....	A	4.10
1445	Valve - Fuel Check (126 & Up) (See 1249).....	C	2.35
1446	Seat - Adjustment - Front.....	A	4.40
1447	Head Set - Radio.....	B	9.00
1448	Microphone - Radio.....	B	5.00
1449	Handle Ass'y. - Flap (Electrol).....	C	3.13
1450	Handle Assembly - Landing Gear (Electrol).....	C	2.98
1451	Handle Assembly - Pump (Electrol).....	C	4.30
1452	Shaft Ass'y-Tail Wheel Shock Absorber (126 & Up) (See 1125).....	A	53.57
1453	Collar-T.W. Shock Absorber (126 & Up) (See 1126).....	A	15.85
1454	Sleeve - T.W. Shock Absorber (126 & Up) (See 1134).....	A	3.00
1455	Cable Assembly - Tail Wheel Lock Release.....	A	1.82
1456	Lock Pin - Tail Wheel.....	A	3.70
1457	Spring - Lock Pin - Tail Wheel.....	A	.12
1458	Strainer - Fuel (301 & Up) (See 1271).....	B	6.96
1459	Mat - Cabin Floor L.H. Fwd. (426 & Up) (See 1376).....	A	1.30
1460	Mat - Cover Door Left Hand (151 & Up).....	A	.75
1461	Mat - Cover Door Right Hand (151 & Up).....	A	.91

Item No.	Nomenclature	Code	List Price
1462	Mat - Cabin Floor R.H. Fwd.(151. & Up).....	A	1.36
1463	Control - Fuel Shut Off.....	B	.95
1464	Anchor Ass'y.- Pressed Pin Tip Antenna (501 & Up)	A	.30
1465	Plate - Fuel Cell Support.....	A	7.21
1466	Antenna Mast.....	B	5.10
1467	Skin - Forward Side Interm Right Hand.....	A	16.25
1468	Skin - Forward Side Intermediate Left Hand.....	A	16.25
1469	Cancelled.....		
1470	Hook - Microphone.....	A	.20
1471	Bulkhead - Station 52 1/2.....	A	13.69
1472	Bulkhead Station 104 1/4.....	A	16.38
1473	Cancelled.....		
1474	Tube - Bow Panel Air Speed Pitot (170 & Up) (See 1066).....	A	3.74
1475	Curtain - Canvas Baggage Compartment.....	A	1.87
1476	Shock Absorber - Tail Wheel.....	A	67.82
1477	Spacers - Propeller.....	A	.27
1478	Chain - Elevator Trim Tab Control (Aft.).....	A	4.85
1479	Post - Center Bow Panel Cabin.....	A	14.59
1480	Cleat Inst. - Bow Mooring.....	A	2.80
1481	Valve - Fuel Shut-Off (126 & Up) (See 1428).....	B	5.02
1482	Fitting - Clevis - L.G. Cylinder.....	C	.79
1483	Fitting - Clevis Wing Flap Cylinder.....	C	.79
1484	Fitting - Clevis Brake Cylinder.....	C	.56
1485	Cover Set - Tail Wheel Dust (For Firestone Wheel)	C	.74
1486	Disc & Plate Set - T.W. Shock Absorber (126 & Up) (See 1129).....	A	16.44
1487	Piston - T.W. Shock Absorber (126 & Up)(See 1128)	A	5.34
1488	Fitting - Float Strut Attachment.....	A	1.54
1489	Kit - Tail Wheel Signal Lite Switch Instrument...	A	4.99
1490	Tube Ass'y.-Control Wheel Column (301 & Up) (See 1217).....	A	16.45
1491	Scissors - L.G.Strut (501 & Up) (See 1093).....	C	8.73
1492			
1493	Hose Ass'y. - Prop. Pitch Change - Hydraulic - (126 & Up) (See 1395 & 1396) Pressure & Return...	A	3.85
1494	Anchor Ass'y. - Fin Antenna (501 & Up)(See 1187).	A	3.35
1495	Cleat - Tail Tie Down.....	A	.37
1496	Release - Tail Wheel Wire Slide.....	B	.66
1497	Gasket - Hull Hand Hole Cover.....	A	.12
1498	Cancelled.....		
1499	Cancelled.....		
1500	Bag - Anchor Stowage.....	A	2.64
1501	Kit - Rear Cabin Stiffener Inst.....	A	8.15
1502	Shaft-Elevator Trim Tab Flexible (308 & Up) (See 1327).....	A	2.82
1503	Rod - Ass'y.- Trim Tab Cont.(308 & Up)(See 1327).	A	2.70
1504	Sleeve - Elev.Trim Tab Cont.(308 & Up)(See 1327).	A	3.04
1505	Hinge Set - Fin To Rudder Upper.....	A	3.05
1506	Hinge Set - Fin To Rudder Lower.....	A	3.25
1507	Hinge Set - Rudder to Fin Upper.....	A	1.52
1508	Hinge Set - Rudder to Fin Lower.....	A	1.59
1509	Angle Set - Rudder Quadrant Support.....	A	2.34
1510	Button - Starter.....	A	.50
1511	Horn & Balance Weight Assembly - Elevator.....	A	25.14
1512	Valve - Brake Hydraulic Bleeder.....	A	.55
1513	Shaft - Engine Tachometer (426 & Up)(See 1161)...		No Price
1514	Harness - Cabin Electric Wiring (426 & Up) (See 1332).....	A	39.92
1515	Harness - Engine Electric Wiring (426 & Up) (See 1333).....	A	11.20
1516	Tachometer - Engine (426 & Up) (See 1160).....		No Price
1517	Gage - Oil Temperature (426 & Up) (See 1159)....		No Price
1518	Gage - Fuel Quantity Indicating (426 & Up) (See 1178).....		No Price
1519	Gage - Oil Pressure (426 & Up) (See 1277).....		No Price
1520	Gage - Fuel Pressure (426 & Up) (See 1276).....		No Price
1521	Ammeter - (426 & Up) (See 1183).....		No Price
1522	Weather Stripping - Rubber Door (6 ft. Long)....		No Price
1523	Handle - Right Hand Cabin Door.....		No Price
1524	Tank Unit-Fuel Measuring (426 & Up) (See 1267)...		No Price
1525	Kit - Engine Exhaust Tail Pipe Clamp.....		No Price
1526	Clamp - Engine Exhaust Tail Pipe L.H.....		No Price
1527	Socket - Wing Float Strut.....		No Price