



Instruction No. 6

Replacement of Wings

When replacing wings, items 1050 and 1067, on airplanes prior to Serial No. 301, the bushings in the rear cross tie must be removed. A new and longer spacer is furnished with each wing which can be inserted thru both sides of the cross tie and rear wing spar. Attachment hardware is also furnished.

RC-3-6
2/18/47